

Operating Instructions

Rhino Magnetic Wand

To collect ferrous metal waste, simply move the end of the Rhino Magnetic Wand over the contaminated areas, and the waste will be lifted by the magnets.


To release the waste, position the wand over a waste-bin or collection tray and pull the release rod. The waste will be released once the internal magnets travel past the black ring. The waste can then be disposed of safely.

During the cleaning, use suitable gloves, and be careful of the exposed magnets as they will attract any ferrous metal object. Keep away from heart pacemakers.

Never handle the Magnetic Wand with hands around the magnets or any area below the black ring.

No maintenance is required.

Magnets engaged



Waste release

