

Operating Instructions

Nailbiter Magnetic Sweeper



To collect ferrous metal waste, simply push the Nailbiter magnetic sweeper over the contaminated ground, and the waste will be lifted by the magnets and stick to the underside.

To remove the collected waste, push the handle forward until it rests on the ground and the silver base (magnets) of the sweeper faces up.

Place the supplied tray in the gap beneath the sweeper and, using the supplied scraper in a downwards motion at 45 degrees to the base of the magnets, scrape the waste off so that it falls into the tray.

Remove the tray before lifting the handle of the sweeper back into the upright operating position.

During the cleaning, use suitable gloves, and be careful of the exposed magnets as they will attract any ferrous metal object. Keep away from heart pacemakers. Always use the side handles when lifting. Never lift with hands underneath the magnets. No maintenance is required.

