i Operating InstructionsSCF Series Magnetic Sweeper

CAUTION - POWERFUL MAGNETS

This product contains a magnetic field and should be kept at a safe distance from electrical equipment, pacemakers, metallic implants, credit cards, and computer equipment.

Fork attachment - Set the distance between the forks appropriately for the sweeper and pick up as if it were a pallet.

Operating height - The sweeper is designed to operate with the wheels off the ground. The height will depend on each application. It is best to experiment to find the best combination of speed and height for your application.

Do not let the wheels run on the ground, this will cause damage. The wheels are to support the sweeper when not in use, to make moving it around easier. Release of waste - We recommend that you lift the sweeper to a height of between 40cm and 1 metre over a sheet, skip, bin or in a designated area. There is a large lever on the side of the magnetic sweeper 'A', simply pull this to release the waste from that has been collected. Then release the lever.

Maintenance - No maintenance is required.

Transport - When transporting the magnetic sweeper, use an appropriate pallet.



